



Home

Installation and support info

Download printer friendly catalog



New Floor Mats for Western Star Trucks!



Safeguard your investment with these attractive, highly-functional floor mats!



WWS 49XFM
Applications: 47X, 49X, and 57X



All driver side floor mats feature one of our exclusive Positive Restraint Systems (PRS) designed to hold the driver's side mat in place.



Heavy Duty borders to catch and retain abrasive debris, caustic materials, liquids, grease and oils harmful to a truck's O.E. flooring.



Driver's Cushioning Safety Heel Pad.



High impact absorbing vertical ribs and textured inlay.



Part# WWS NUWSCAB



Unique trim to fit feature accommodates various engine options and interiors, all configurations retain borders. (to see trim instructions click on the "support button"). Fits most models (post Constellation and 900). Does not fit the new X-Cabs (not for 47X, 49X, 57X). Compare WWS 3331A (below) to WWS NUWSCAB footprint and your cab's floor plan for correct fit.

Part# WWS WS3331A
Fits WS900. Constellation. (Most models)



Floor mat part numbers won't necessarily fit all years, or all configurations for the Truck model listed. Truck manufacturers make changes to cab interiors periodically that can affect the fit of auxiliary floor mats. Truck models can have multiple floor plans due to options, accessories, and build variances. To check for proper fit; ensure that the floor mat lays flat against the O.E. flooring, and does not interfere with the control pedals. Please see Installation Instructions on our "Support tab" at www.productsalesco.com for important safety information. To purchase these products, contact or visit an authorized WESTERN STAR Dealership.

Dealer note; Available through your PDC program.



VISIT US AT:
productsalesco.com
TO REACH US CLICK ON: "CONTACT US"

